

## Module Temperature Sensors Tm-Pt1000 / Tm-Pt1000-box



### Safety Instructions

The installation and assembly of electrical equipment must be carried out by electrically qualified persons. The sensor may not be used with equipment whose direct or indirect purpose is to prevent death or injury, or whose operation poses a risk to humans, animals or property.


### Warranty and Liability

The sensor is designed for the measurement of a surface temperature. The warranty is for 1 year from the date of the invoice for the intended use. IMT Technology does not accept any liability for possible losses or damage due to the incorrect usage of the sensor. Liability for consequential damages is excluded.

### Mounting Instructions

The sensor element is mounted by gluing the aluminium block directly to the measurement surface. The surface must be dry, clean and degreased. Cleaning should NOT be done with glass cleaner, as some glass cleaners contain additives to prevent soiling after cleaning and these additives also prevent adhesion. Isopropyl Alcohol or Ethanol is recommended for cleaning. Temperature sensors shall be placed in representative locations to capture the range of variation and allow determination of an effective average. For crystalline silicon modules, select the centre-most cell within the module, or, when the module is built with even numbers of rows or columns of cells, select one of the cells closest to the centre. For bifacial modules, rear-side temperature sensors and wiring shall obscure < 10 % of the area of any cell, and wiring should be routed in between cells when possible.




It is also recommended using an extra fixing with silicone or Sikaflex, particularly for module temperature above 75°C. The sensor cable needs a cable grip close to the sensor housing.



If mounted outdoors, avoid direct exposure to sunlight and rain to the sensor housing (aluminium block) and sensor case. If necessary, provide protection from the sun and rain.



The through holes used to fix the sensor to a stable and suitable surface shall be accessible when the housing is opened. The tightening torque of the case cover is 180 Ncm.

When installing the sensor Tm-Pt1000-box, the cables must be routed downwards from the housing.



### Electrical Connection

The sensors are designed for safety extra-low voltage (SELV) operation. For keeping the accuracy of the sensor a 4 wire measurement is strongly recommended. Due to the self-heating, the wire current affects the accuracy of the measurement. Thus, the same should not exceed 0.1 mA.



### Maintenance

Scope of the regularly check (at least once a year): Cleaning, external damage, mechanical fastening, cable laying and any damage to the cable. Should damage be found that degrades the function or safety, the sensor is to be replaced. A recalibration is recommended at least every 3 years.

### Technical Data

Type	Tm-Pt1000	Tm-Pt1000-box
Sensor element	Pt1000 class A as per EN 60751	
Sensor housing	Self-adhesive aluminium block, 35 mm x 12 mm x 6 mm	
Sensor cable (Pt1000)	Length: 3 m, PUR coated, shielded (LiYC11Y, 2 x 0.25 mm <sup>2</sup> )	
Operating temperature	-40 to +90 °C (see installation instruction)	
Connection	Wires of sensor cable	Spring terminals
Case dimension / protection level	–	64 mm x 58 mm x 34 mm
Weight	70 g	240 g

### Scope of delivery

- Sensor incl. pre-assembled connecting cable (Tm-Pt1000) respectively  
Sensor incl. case with spring terminals (Tm-Pt1000-box)
- Instruction sheet

### Intelligent Measurement & Testing